

VSH Tectite

Flow charts - Head loss/Pressure loss
When used with copper tube

